

Fisher-Price®

R4749



www.fisher-price.com

Consumer Information



WARNING

Prevent Entanglement Injury


- This product may not attach to all crib designs. Do not add additional strings or straps to attach to a crib or playpen.
 - Use **ONLY** attached to a crib.
-
- Please keep this instruction sheet for future reference, as it contains important information.
 - Requires four “C” batteries (included) and two “AAA” (LR03) **alkaline** batteries (not included) for operation.
 - Adult assembly is required for battery installation.
 - Tool required for battery installation: Phillips screwdriver (not included).

Battery Safety Information

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of this product in a fire. The batteries inside may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

Soother Battery Replacement



For best performance, we recommend replacing the batteries that came with the soother with four, new "C" (LR14) alkaline batteries.


- Locate the battery compartment on the back of the soother.
- Loosen the screws in the battery compartment door and remove the door.
- Remove the exhausted batteries and throw them away.
- Insert four, new "C" (LR14) **alkaline** batteries.

Hint: We recommend **alkaline** batteries for longer battery life.

- Replace the battery compartment door and tighten the screws.
- If the soother begins to operate erratically, you may need to reset the electronics. Slide the power/volume switch off and then back on.

IMPORTANT! Under normal use conditions, the batteries in the soother will require replacement more often than the batteries in the remote. When sounds and lights from this toy become faint or stop, it's time for an adult to change the batteries.

Remote Battery Installation



- Locate the battery compartment on the back of the remote.
- Loosen the screw in the battery compartment door and remove the door.
- Insert two, new "AAA" (LR03) **alkaline** batteries.

Hint: We recommend **alkaline** batteries for longer battery life.

- Replace the battery compartment door and tighten the screw.
- If the remote begins to operate erratically, you may need to reset the electronics. Remove the batteries and replace them.

Consumer Information

**CONSUMER ASSISTANCE**
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)
service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: [Mattel UK Ltd. Vanwall Business Park,
Maidenhead SL6 4UB](http://Mattel UK Ltd. Vanwall Business Park, Maidenhead SL6 4UB). Helpline: 01628 500303.
www.service.mattel.com/uk

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

ICES-003

This Class B digital apparatus complies with Canadian ICES-003. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

NMB-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes:

(1) il ne doit pas produire de brouillage et
(2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

FCC Statement (United States Only)


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Crib Attachment


IMPORTANT! Always attach all provided fasteners (strings, straps, clamps, etc.) tightly to a crib or playpen according to the instructions. Do not add additional strings or straps to attach to a crib. Check frequently.



IMPORTANT! If you are attaching this toy to a crib side rail that can be lowered and raised, make sure the crib side rail is in the raised (locked) position whenever a child is in the crib.


- Position the toy inside the crib.
- Wrap the attachment strap around the top of the crib rail.
- Slide the end of the attachment strap under the tabs on the back of the toy.
- Fasten the attachment strap slot to the peg on the back of the toy.

NOTE: This toy should be snug against the crib rail and spindles. Use the strap slot that provides the tightest fit.




- Tie the toy's strings to a crib spindle.

NOTE: It is better to tie the strings in a knot than a bow, since a bow may be easily untied.



- Make sure the distance between the bottom of the product and the crib mattress is **at least 7 inches (18cm)**.
- If the distance is less than 7 inches (18cm), readjust the attachment strap to lift the product; or lower the crib mattress.

Use




IMPORTANT!

- In the unlikely event that use of the remote interferes with normal use of other remote controlled equipment, such as televisions, stereos, or use of other electronic or battery powered appliances interfere with operation of the soother, do not use both at the same time.
- For best performance between the soother and the remote, avoid using the remote in areas of bright light. In bright natural or artificial light, you may notice loss of range. Move the soother, or reduce the amount of light, to improve performance.
- When using the remote, make sure the arrow on the soother is pointing towards the transmitter window on the remote. For best results, make sure the path between the transmitter window on the remote and the soother are in a direct line and free of obstacles. Position the soother so the arrow points to an area that you are mostly likely to use the remote.

Soothing Sounds



Power/Volume Switch



Mode Switch

- Slide the power/volume switch on the soother to ON with low volume (single speaker icon) or ON with high volume (two speaker icons). When you are finished using this product, slide the power/volume switch OFF (circle with a dot).
- Slide the mode switch to: (speaker and light bulb icon) turns on sounds, lights and projector; (speaker and projector icon) turns on sounds and projector; (single speaker icon) turns on sounds only.
- Press the song select button to change the song.

Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This toy has no consumer serviceable parts. Do not take this toy apart.



- Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).